

## FAKULTI SAINS Faculty of Science

# GWI No.: FS/LM/GWI010 Revision No.: 00 Effective Date: 01.12.2020 Page No.: Page 1 of 1

### GENERAL WORK INSTRUCTION: CENTERED AUTOCLAVE OPERATION

#### 1.0 OPERATION HOUR

DAY	ITEM	TIME
Sunday - Wednesday	Apparatus & mediums	9.00 am & 12.00 pm
		2.30 pm
Thursday	Waste	9.00 am & 12.00 pm

#### 2.0 PROCEDURE

Fill up the form PM012015 and leave it in the container provided.



Write the details in the logbook provided and labels each of your items.



Leave the items in the container at least 30 minutes before the operation hour.



Make sure to you collect your own items at the end of the sessions (2 hours later).

#### **Notes:**

- 1. Priority is given to laboratory which has no autoclave.
- 2. Your cooperation to follow the operation hour is highly appreciated.

Prepared by: Reviewed by: Approved by: AMALINA BINTI RAMLI MUHAMAB WZAINI BIN RAMLI Penolong Pegawai Sains Pegawai Sains DR. ALINA WAGIRAN PENGURUS MAKMAL Fakulti Sains Fakulti Sains FAKULTI SAINS Universiti Teknologi Malaysia Universiti Teknologi Malaysia UNIVERSITI TEKNOLOGI MALAYSIA 81310 Johor Bahru, Johor 81310 UTM JOHOR BAHRU 81310 Johor Bahru Johor 2020 Date: Date: Date: 31 2020