through archaeological investigation and appropriate preservation of archaeological findings.

**12.** Traffic inside a historic town or urban area must be controlled and parking areas must be planned so that they do not damage the historic fabric or its environment.

**13.** When urban or regional planning provides for the construction of major motorways, they must not penetrate a historic town or urban area, but they should improve access to them.

**14.** Historic towns should be protected against natural disasters and nuisances such as pollution and vibrations in order to safeguard the heritage and for the security and well-being of the residents.

Whatever the nature of a disaster affecting a historic town or urban area, preventative and repair measures must be adapted to the specific character of the properties concerned.

**15.** In order to encourage their participation and involvement, a general information programme should be set up for all residents, beginning with children of school age.

**16.** Specialised training should be provided for all those professions concerned with conservation.