



Cut and fill

The process of taking away and adding earth to change landform is known as 'cut and fill'. Frequently the landscape architect may seek to balance the 'cut' (land removed) and 'fill' (land added) within their topographic design to reduce the need for transporting material elsewhere. Balancing cut and fill is desirable for financial and energy-saving reasons.