


## Supersonic Flow Turning

- For normal shocks, flow is perpendicular to shock
  - no change in flow direction
- How does supersonic flow change direction, i.e., make a turn
  - either slow to subsonic ahead of turn (can then make gradual turn) **=bow shock**
  - go through non-normal wave with sudden angle change, i.e., **oblique shock** (also expansions: see later)
- Can have straight/curved, 2-d/3-d oblique shocks
  - will examine straight, 2-d oblique shocks




Oblique Shocks -1  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Oblique Shock Waves

- Recall Mach wave
  - consider infinitely thin body
  - no flow turn required
  - infinitesimal wave
$$\mu = \sin^{-1}(1/M_1)$$
- Oblique shock
  - consider finite-sized wedge, half-angle,  $\delta$
  - flow must undergo compression to turn
  - if attached shock
    - ⇒ **oblique shock** at angle  $\theta$
  - similar for concave corner



Oblique Shocks -2  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.


**AE3450**

## Equations of Motion

- Governing equations
  - same approach as for normal shocks
  - use conservation equations and state equations
- Conservation Equations
  - mass, energy and momentum
  - this time 2 momentum equations - 2 velocity components for a 2-d oblique shock
- Assumptions
  - steady flow (stationary shock), inviscid except inside shock, adiabatic, no work but flow work

## Control Volume

- Pick control volume along shock
- Divide velocity into two components
  - one tangent to shock,  $v_t$
  - one normal to shock,  $v_n$
- Angles from geometry
  - $v_{1n} = v_1 \sin \theta$ ;  $v_{1t} = v_1 \cos \theta$
  - $v_{2n} = v_2 \sin(\theta - \delta)$ ;  $v_{2t} = v_2 \cos(\theta - \delta)$
  - $M_{1n} = M_1 \sin \theta$ ;  $M_{1t} = M_1 \cos \theta$
  - $M_{2n} = M_2 \sin(\theta - \delta)$ ;  $M_{2t} = M_2 \cos(\theta - \delta)$



## Conservation Equations

- **Mass**

$$\int_{CS} \rho (\vec{v}_{rel} \cdot \vec{n}) dA = 0$$

$$\rho_1 v_{1n} A_n + \rho_1 v_{1t} \frac{A_t}{2} + \rho_2 v_{2t} \frac{A_t}{2} =$$

$$\rho_2 v_{2n} A_n + \rho_2 v_{1t} \frac{A_t}{2} + \rho_2 v_{2t} \frac{A_t}{2}$$

$$\rho_1 v_{1n} = \rho_2 v_{2n} \quad (1)$$

- **Momentum**


$$\int_{CS} p \cdot \vec{n} dA = \int_{CS} \rho \vec{v} (\vec{v}_{rel} \cdot \vec{n}) dA$$

tangent  $(p_1 + p_2) \frac{A_t}{2} = (p_1 + p_2) \frac{A_t}{2} = v_{1t} (-\rho_1 v_{1n} A_n) + v_{2t} (\rho_2 v_{2n} A_n)$

$$v_{1t} = v_{2t}$$

normal  $p_1 A_n - p_2 A_n = v_{1n} (-\rho_1 v_{1n} A_n) + v_{2n} (\rho_2 v_{2n} A_n)$

$$p_1 - p_2 = \rho_1 v_{1n}^2 + \rho_2 v_{2n}^2 \quad (2)$$



Oblique Shocks -5  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**


## Conservation Equations (con't)

- **Energy**

$$\rho_1 v_{1n} A_n \left( h_1 + \frac{v_1^2}{2} \right) = \rho_2 v_{2n} A_n \left( h_2 + \frac{v_2^2}{2} \right)$$

$$h_1 + \frac{v_{1n}^2}{2} + \frac{v_{1t}^2}{2} = h_2 + \frac{v_{2n}^2}{2} + \frac{v_{2t}^2}{2}$$

$$h_1 + \frac{v_{1n}^2}{2} = h_2 + \frac{v_{2n}^2}{2} \quad (3)$$



- Eq's. (1)-(3) are same equations used to characterize normal shocks (VII.1-3) with  $v_n \rightarrow v$

- So oblique shock acts like normal shock in direction normal to wave

–  $v_t$  constant, but  $M_{t1} \neq M_{t2}$   $\frac{M_{t2}}{M_{t1}} = \sqrt{\frac{v_{t2}/a_2}{v_{t1}/a_1}} \Rightarrow \frac{M_{t2}}{M_{t1}} = \sqrt{\frac{T_1}{T_2}}$  (VII.20)

Oblique Shocks -6  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.


**AE3450**

## Oblique Shock Relations

- To find conditions across shock, use M relations from normal shocks, e.g., (VII.5-17) but replace

$$M_1 \rightarrow M_1 \sin\theta = M_{1n}$$

$$M_2 \rightarrow M_2 \sin(\theta-\delta) = M_{2n}$$



- Mach Number (after shock)**

$$\text{from (VII.11)} \quad M_2^2 = \left( M_1^2 + \frac{2}{\gamma-1} \right) / \left( \frac{2\gamma}{\gamma-1} M_1^2 - 1 \right)$$

$$M_2^2 \sin^2(\theta - \delta) = \left( M_1^2 \sin^2 \theta + \frac{2}{\gamma-1} \right) / \left( \frac{2\gamma}{\gamma-1} M_1^2 \sin^2 \theta - 1 \right) \quad (\text{VII.21})$$

Oblique Shocks -7  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Oblique Shock Relations (con't)

- Static Properties**

(from VII.12)


$$\frac{p_2}{p_1} = \frac{2\gamma}{\gamma+1} M_1^2 \sin^2 \theta - \frac{\gamma-1}{\gamma+1} \quad (\text{VII.22})$$

(from VII.18)

$$\frac{v_{1n}}{v_{2n}} = \frac{p_2}{p_1} = \frac{(\gamma+1)M_1^2 \sin^2 \theta}{(\gamma-1)M_1^2 \sin^2 \theta + 2} \quad (\text{VII.23})$$

(from VII.9)

$$\frac{T_2}{T_1} = \frac{\left(1 + \frac{\gamma-1}{2} M_1^2 \sin^2 \theta\right) \left( \frac{2\gamma}{\gamma-1} M_1^2 \sin^2 \theta - 1 \right)}{M_1^2 \sin^2 \theta (\gamma+1)^2 / 2(\gamma-1)} \quad (\text{VII.24})$$



Oblique Shocks -8  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Oblique Shock Relations (con't)

- **Stagnation Properties**

$T_o$  (from energy conservation)

$$T_{o2} = T_{o1}$$

$p_o$  (from VII.14)  $p_{o2}/p_{o1} = (T_1/T_2)^{\gamma/\gamma-1} (p_2/p_1)$  since function of static property ratios, don't have to factor in  $p_{ot}$  v.  $p_{on}$   
(from VII.13)

$$\frac{p_{o2}}{p_{o1}} = \left[ \frac{\frac{\gamma+1}{2} M_1^2 \sin^2 \theta}{1 + \frac{\gamma-1}{2} M_1^2 \sin^2 \theta} \right]^{\frac{\gamma}{\gamma-1}} \left[ \frac{2\gamma}{\gamma+1} M_1^2 \sin^2 \theta - \frac{\gamma-1}{\gamma+1} \right]^{\frac{1}{1-\gamma}}$$


(VII.25)

Oblique Shocks -9  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Wave/Shock Angle

- Equations above are functions of  $M_1$ ,  $\theta$  (shock angle) and  $\delta$  (turning angle)
- Is there a relationship between them?



(from VII.23)  $\frac{v_{1n}}{v_{2n}} = \frac{(\gamma+1)M_1^2 \sin^2 \theta}{(\gamma-1)M_1^2 \sin^2 \theta + 2}$  (from geometry)  $\frac{v_{1t}}{v_{2t}} = \frac{v_{1t} \tan \theta}{v_{2t} \tan(\delta - \theta)}$

Alternate Eq'n.  
 $\tan \delta = \frac{(1/\tan \theta)(M_1^2 \sin^2 \theta - 1)}{\frac{\gamma+1}{2} M_1^2 - (M_1^2 \sin^2 \theta - 1)}$

$\tan \delta = \frac{(2/\tan \theta)(M_1^2 \sin^2 \theta - 1)}{M_1^2(\gamma + \cos 2\theta) + 2}$  (VII.26)


So to find oblique shock solution, need 2 indep. parameters, e.g.,  $M_1$  and  $\delta$

Oblique Shocks -10  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Use of Shock Tables

- Since just replacing  
 $M_1 \rightarrow M_1 \sin\theta$   
 $M_2 \rightarrow M_2 \sin(\theta-\delta)$ 
  - can also use normal shock tables
  - use  $M_1' = M_1 \sin\theta$  to look up property ratios
  - $M_2' = M_2 / \sin(\theta-\delta)$ , with  $M_2'$  from normal shock tables
- **Warning**
  - do not use  $p_1/p_{o2}$  from tables
  - only gives  $p_{o2}$  associated with  $v_{2n}$ , not  $v_{2t}$




Oblique Shocks -11  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Oblique Solution Summary

- If given  $M_1$  and shock angle,  $\theta$ 
  1. Find  $\delta$  from VII.26 or use oblique shock charts (Appendix C in John)
  2. Calculate  $M_{1n} = M_1 \sin\theta$
  3. Use normal shock tables or Mach relations, e.g., VII.22-25 to get property ratios
  4. Get  $M_2$  from  $M_2 = M_{2n} / \sin(\theta-\delta)$  or VII.21
- If given  $M_1$  and turning angle,  $\delta$ 
  1. Find  $\theta$  from (iteration) VII.26 or use oblique shock charts (e.g., Appendix C in John)
  2. Steps 2-4 above




Oblique Shocks -12  
Copyright © 2001, 2011 by Jerry M. Seitzman. All rights reserved.

**AE3450**

## Example #1 – Known Shock Angle

- Given: Uniform Mach 1.5 air flow ( $p=50 \text{ kPa}$ ,  $T=345\text{K}$ ) approaching sharp concave corner. Oblique shock produced with shock angle of  $60^\circ$



- Find:

- $T_{o2}$
- $p_2$
- $\delta$  (turning angle)

- Assume: TPG/CPG with  $\gamma=1.4$ , steady, adiabatic, no work, inviscid except for shock,....

**AE3450**


## Example #1 (con't)

- Analysis:

- $T_o$

$$T_{o2} = T_{o1} = T_1 \left( 1 + \frac{\gamma-1}{2} M_1^2 \right)$$

$$= 345 \text{K} \left( 1 + 0.2(1.5)^2 \right) = 500 \text{K}$$



- $p_2$

- calculate normal component

$$M_{1n} = M_1 \sin \theta = 1.5 \sin 60^\circ = 1.30 \quad (\text{B.1}) \Rightarrow M_{2n} = 0.786$$

$$p_2 = (p_2/p_1)p_1 = (1.805)50 \text{kPa} = 90.3 \text{kPa} \quad p_2/p_1 = 1.805$$

$$T_2/T_1 = 1.191$$

- $\delta$  (from VII.26)


$$\tan \delta = \frac{(1/\tan 60^\circ)(1.5^2 \sin^2 60^\circ - 1)}{\frac{2.4}{2} 1.5^2 - (1.5^2 \sin^2 60^\circ - 1)} \Rightarrow \delta = 11.2^\circ$$

NOTE:  $M_2 = M_{2n}/\sin(\theta - \delta) = 1.04 > 1$  Supersonic flow okay after oblique shock

**AE3450**

## Example #2 – Known Turn Angle

- Given: Uniform Mach 2.4, cool, nitrogen flow passing over 2-d wedge with 16° half-angle.



- Find:

$$\theta, p_2/p_1, T_2/T_1, p_{o2}/p_{ol}, M_2$$


- Assume: N<sub>2</sub> is TPG/CPG with  $\gamma=1.4$ , steady, adiabatic, no work, inviscid except for shock,....

## Example #2 (con't)

- Analysis:

–  $\theta$  (from VII.26)

$$\tan 16^\circ = \frac{(2/\tan \theta)(2.4^2 \sin^2 \theta - 1)}{2.4^2(1.4 + \cos 2\theta) + 2}$$



iterate  $\theta = 39.4^\circ$  or from John App. C: oblique shock charts

– use shock relations calculate normal component

$$M_{1n} = M_1 \sin \theta = 2.4 \sin 39.4^\circ = 1.52$$

$$(B.1) \Rightarrow M_{2n} = 0.6935; p_2/p_1 = 2.535; T_2/T_1 = 1.335; p_{o2}/p_{ol} = 0.9227$$

$$M_2 = M_{2n}/\sin(\theta - \delta) = 1.75 \quad \text{Supersonic after shock}$$

## Example #2 (con't)

- **Analysis (con't):**

- can find second solution for  $\theta$

$$\tan 16^\circ = \frac{(2/\tan \theta)(2.4^2 \sin^2 \theta - 1)}{2.4^2(1.4 + \cos 2\theta) + 2}$$

in addition to  $39.4^\circ$     $\theta = 82.1^\circ$

- use shock relations calculate normal component

$$M_{1n} = M_1 \sin \theta = 2.4 \sin 82.1^\circ = 2.38$$


previous solution **2.535**

$$(B.1) \Rightarrow M_{2n} = 0.5256; p_2/p_1 = 6.425; T_2/T_1 = 1.335; p_{o2}/p_{oi} = 0.9227$$

**1.75**

$$M_2 = M_{2n}/\sin(\theta - \delta) = 0.575 \quad \text{Now subsonic after shock}$$

- VII.26 generally has **2 solutions for  $\theta$ : Strong and Weak** oblique shocks




**AE3450**

## Alternate Approach

- Possible to find **direct relationship\*** for  $\theta$  as function of  $M_1$  and  $\delta$

$$\tan \theta = \frac{M_1^2 - 1 + 2\lambda \cos\left(\frac{4\pi\alpha + \cos^{-1}\chi}{3}\right)}{3\left(1 + \frac{\gamma-1}{2}M_1^2\right)\tan \delta} \quad (\text{VII.27})$$



Removes iteration requirement... just longer equations

$$\lambda = \sqrt{(M_1^2 - 1)^2 - 3\left(1 + \frac{\gamma-1}{2}M_1^2\right)\left(1 + \frac{\gamma+1}{2}M_1^2\right)\tan^2 \delta}$$

$$\chi = \frac{1}{\lambda^3} \left[ (M_1^2 - 1)^3 - 9\left(1 + \frac{\gamma-1}{2}M_1^2\right)\left(1 + \frac{\gamma-1}{2}M_1^2 + \frac{\gamma+1}{4}M_1^4\right)\tan^2 \delta \right]$$

$$\alpha = \begin{cases} = 0 & \text{strong shock solution} \\ = 1 & \text{weak shock solution} \end{cases}$$